

Mundo EP8 10S

ASSEMBLY NOTICE



- BTR: 3mm, 4mm, 5mm, and 6mm
- Torx T25
- Spanners: 15mm, 10mm
- Long-nose pliers
- Cutting pliers
- Pump
- Grease



1

- EN: Remove all packaging carefully. Check the contents.
- FR: Retirer tous les emballages avec précaution. Vérifier le contenu.
- DE: Verpackung vorsichtig entfernen. Inhalt überprüfen.

> Cutting pliers

2

- EN: Put the handlebars in place, fine adjustment will be done later
- FR: Mettre le guidon en place, les ajustements fins seront faits plus tard
- DE: Lenker in Position bringen, die Feineinstellung erfolgt später

> BTR 4mm



3

- EN: Mount the kickstand
- FR: Monter la béquille
- DE: Montiere den Ständer

> BTR 6mm

Mundo EP8 10S ASSEMBLY NOTICE

5

- EN: Assemble the Sideloaders
- FR: Assembler les Sideloaders
- DE: Baue die Sideloaders zusammen

> BTR 4mm, 5mm



6

- EN: Install the pedals. Note: Left pedal screws counterclockwise, right pedal clockwise.
- FR: Installer les pédales. Remarque : la pédale gauche se visse antihoraire, la droite horaire.
- DE: Pedale installieren. Hinweis: Links gegen den Uhrzeigersinn, rechts im Uhrzeigersinn.

> Spanner 15mm
> Grease

7

- EN: Insert seatpost and tighten
- FR: Insérer la tige de selle et serrer
- DE: Sattelstütze einführen und festziehen

> BTR 4mm
> Grease



8

- EN: Install the front fender, then mount the front light and the Deflopilator
- FR: Installer le garde-boue avant, puis monter le phare avant et le Deflopilator
- DE: Vorderradschutzblech installieren, dann das Vorderlicht und den Deflopilator montieren

> BTR 4mm, 5 mm
> 10mm spanner
> Long needle-pliers

Mundo EP8 10S ASSEMBLY NOTICE

9

- EN: Put the front wheel on
- FR: Mettre la roue avant en place
- DE: Vorderrad montieren

> BTR 6mm



10

- EN: Install the brake caliper, press the front brake lever to align, then tighten.
- FR: Installer l'étrier de frein, appuyer sur le levier de frein avant pour aligner, puis serrer.
- DE: Bremszange montieren, vorderen Bremshebel drücken, ausrichten und festziehen.

> Torx T25



11

- EN: Mount the stem, adjust the handlebars
- FR: Monter la potence, ajuster le guidon
- DE: Vorbau montieren, Lenker einstellen

> BTR 4mm, 5mm



12

- EN: Install the bell and all the reflectors
- FR: Installer la sonnette et tous les réflecteurs
- DE: Montiere die Klingel und alle Reflektoren

> Screwdriver (potentially)

Mundo EP8 10S ASSEMBLY NOTICE

13

- EN: Adjust display position and tighten. For controls, refer to the Shimano user manual
- FR: Ajuster la position de l'écran et serrer. Pour les commandes, voir le manuel Shimano
- DE: Displayposition einstellen und festziehen. Für die Steuerung siehe Shimano-Handbuch

> BTR 3mm



14

- EN: Inflate tires to the recommended manufacturer pressure
- FR: Gonfler les pneus à la pression recommandée par le fabricant
- DE: Reifen auf den vom Hersteller empfohlenen Druck aufpumpen

> Pump



15

- EN: Final safety check: Tighten both wheels, secure the cockpit, and check the brakes (bed in brake pads).
- FR: Dernière vérification de sécurité : serrer les roues, sécuriser le poste de pilotage et vérifier les freins (penser au rodage des plaquettes).
- DE: Letzte Sicherheitskontrolle: Räder festziehen, Cockpit sichern und Bremsen prüfen (Bremsbeläge einfahren).

**Any issues?
Drop us a line**

yubabikes.eu/contact

**Don't forget to
register your bike!**

yubabikes.eu/register